INSTRUCTIONS FOR WIRING STOCK#28-3730 CHASSIS, TRANSFORMER-51-1229 - STEREO PHONE AMPLIFIER CHASSIS

#1 CONNECT TWO GREEN WIRES OF TRANSFORMER TO TWO YELLOW WIRES OF AMPLIFIER CHASSIS ON RIGHT SIDE
DO NOT USE BLACK WIRE (TAPE)

#2 CONNECT BLACK AND RED WIRE OF TRANSFORMER TO 120VAC LINE

#3 YELLOW HARNESS WITH

RED WIRE LUG	LEFT CHANNEL INPUT
WHITE WIRE LUG	RIGHT CHANNEL INPUT
SHIELDED LUG	COMMON GROUND INPUT

#4 FRONT CONTROLS - VOLUME - BALANCE - TONE

#5 RIGHT-LEFT CHANNEL SPEAKERS CONNECT TO TERMINAL JACK BOARD

#6 HEADPHONE PLUG INTO 1/4" HEADPHONE JACK